

STORM WATER-BLOCK AMD® 64, FX, X2, Sempron®, Socket AM2 ADAPTER KIT

REMOVE THE FACTORY INSTALLED HOLD-DOWN PLATE FIRST, AND REPLACE WITH THE PROVIDED REPLACEMENT PLATE, THEN PROCEED WITH INSTALLATION OF THE WATER-BLOCK AS SHOWN BELOW.

ITEM NO.	PART NUMBER	DESCRIPTION	QTY
1.1	motherboard		n/a
1.2	Back-Plate	Motherboard backplate	n/a
2.1	STORM-HOLD-DOWN-AM2	Storm Universal hold-down plate	1
3	6-32x1.25-philips	Philips screw	4
4	washer-0148x0266x0040-91007A619	Lock Washer #6 x 0.040	4
5	13LTS5002190973	Storm AM2 Nylon spacer	4

